

Asset number	TR13
Make Model	MT5010-AVO06x1281
chassis hrs	21074
<u>Component hrs</u>	
Engine	4929
Transmission	8988
Rear axle	909
Front axle	2191
torque convertor	8988

tyre wear %	Asset	Pos1	Pos 2	Pos 3	Pos 4
	TR13	40%	40%	40%	40%

Plant Item	Plant Description	Start Date	Finish Date	Work Type	W/Order	Work Description
TR13	ATLAS COPCO MT5010	11-Jul-11	11-Jul-11	BD	W2000313	Replace solenoid on gear selector and gasket.
TR13	ATLAS COPCO MT5010	10-Aug-11	10-Aug-11	PM	W2000394	Weld coolant tank and hyd tank
TR13	ATLAS COPCO MT5010	22-Aug-11	24-Aug-11	PM	W2000427	MT5010 1,000HR SERVICE
TR13	ATLAS COPCO MT5010	29-Aug-11	30-Aug-11	BD	W2000462	P/brake fault, repair cab proxy wiring
TR13	ATLAS COPCO MT5010	16-Sep-11	16-Sep-11	PM	W2000518	REPLACE WINDOW
TR13	ATLAS COPCO MT5010	3-Oct-11	3-Oct-11	BD	W2000571	replace up box yoke retaining plate and bolt.
TR13	ATLAS COPCO MT5010	13-Oct-11	13-Oct-11	PM	W2000589	replace lube bowl
TR13	ATLAS COPCO MT5010	21-Oct-11	21-Oct-11	PM	W2000607	c/o exhaust gaskets
TR13	ATLAS COPCO MT5010	24-Oct-11	24-Oct-11	PM	W2000610	c/o faulty fuel sender
TR13	ATLAS COPCO MT5010	27-Oct-11	27-Oct-11	PM	W2000734	MT5010 250HR SERVICE
TR13	ATLAS COPCO MT5010	7-Nov-11	7-Nov-11	PM	W2000646	MT5010 250HR SERVICE
TR13	ATLAS COPCO MT5010	25-Nov-11	30-Jun-12	PM	W2000708	TR13 - General Consumables FY 2011/2012
TR13	ATLAS COPCO MT5010	30-Nov-11	30-Nov-11	PM	W2000724	fit new batteries
TR13	ATLAS COPCO MT5010	22-Dec-11	28-Dec-11	PM	W2000778	c/o cracked site gauge
TR13	ATLAS COPCO MT5010	15-Jan-12	15-Jan-12	PM	W2000828	MT5010 500HR SERVICE
TR13	ATLAS COPCO MT5010	18-Jan-12	17-Jan-12	BD	W2000834	c/o failed fan belt tensioner spring
TR13	ATLAS COPCO MT5010	2-Feb-12	3-Feb-12	BD	W2000885	repair failed engine oil pressure sender
TR13	ATLAS COPCO MT5010	5-Feb-12	5-Feb-12	PM	W2000894	MT5010 250HR SERVICE
TR13	ATLAS COPCO MT5010	22-Feb-12	27-Apr-12	PM	W2000948	c/o rusted air cleaner housings
TR13	ATLAS COPCO MT5010	2-May-12	7-May-12	BD	W2001231	C/o failed belt tensioner idler pulley
TR13	ATLAS COPCO MT5010	16-May-12	22-May-12	PM	W2001344	fit new interior door handle
TR13	ATLAS COPCO MT5010	13-Jun-12	5-Jul-12	PM	W2001534	MT5010 250HR SERVICE
TR13	ATLAS COPCO MT5010	1-Jul-12	1-Jul-13	PM	W2001892	TR13 - General Consumables FY 2012/2013
TR13	ATLAS COPCO MT5010	18-Jul-12	18-Jul-12	DA	W2001750	repair damage to cab
TR13	ATLAS COPCO MT5010	20-Aug-12	21-Aug-12	PM	W2001977	MT5010 250HR SERVICE
TR13	ATLAS COPCO MT5010	3-Sep-12	4-Sep-12	PM	W2002073	MT5010 1,000HR SERVICE
TR13	ATLAS COPCO MT5010	3-Oct-12	3-Oct-12	PM	W2002309	Daily, add 4 litres trans oil
TR13	ATLAS COPCO MT5010	4-Oct-12	4-Oct-12	PM	W2002312	daily
TR13	ATLAS COPCO MT5010	13-Oct-12	13-Oct-12	BD	W2002360	c/o blown fuel hose
TR13	ATLAS COPCO MT5010	15-Oct-12	15-Oct-12	BD	W2002362	Install fuel hose
TR13	ATLAS COPCO MT5010	2-Nov-12	2-Nov-12	PM	W2002409	MT5010 250HR SERVICE
TR13	ATLAS COPCO MT5010	22-Nov-12	22-Nov-12	PM	W2002474	strip rear final drives and press test for leakage
TR13	ATLAS COPCO MT5010	28-Nov-12	5-Dec-12	PM	W2002462	fit auto lube system
TR13	ATLAS COPCO MT5010	5-Dec-12	7-Dec-12	BD	W2002552	investigate hour meter not working-wiring
TR13	ATLAS COPCO MT5010	10-Dec-12	17-Dec-12	PM	W2002560	MT5010 250HR SERVICE
TR13	ATLAS COPCO MT5010	10-Dec-12	8-Dec-12	BD	W2002592	replace a/c condensor
TR13	ATLAS COPCO MT5010	13-Dec-12	13-Dec-12	BD	W2002633	replace TPS sensor
TR13	ATLAS COPCO MT5010	23-Jan-13	23-Jan-13	PM	W2002852	MT5010 1,000HR SERVICE
TR13	ATLAS COPCO MT5010	28-Jan-13	30-Jan-13	PM	W2002851	replace door latch
TR13	ATLAS COPCO MT5010	5-Feb-13	5-Feb-13	BD	W2002964	eng cutting out-fire suppression box
TR13	ATLAS COPCO MT5010	13-Feb-13	13-Feb-13	PM	W2003002	repair/straighten grag rails
TR13	ATLAS COPCO MT5010	13-Feb-13	17-Feb-13	PM	W2003030	Replace cab safety pins on Tr08 and TR13
TR13	ATLAS COPCO MT5010	17-Feb-13	17-Feb-13	PM	W2003072	MT5010 250HR SERVICE
TR13	ATLAS COPCO MT5010	26-Feb-13	28-Feb-13	PM	W2003114	replace air filter housing
TR13	ATLAS COPCO MT5010	28-Feb-13	28-Feb-13	BD	W2003161	repair wiring harness to trans temp sender,
TR13	ATLAS COPCO MT5010	7-Mar-13	27-Mar-13	BD	W2003181	repair trans temp guage
TR13	ATLAS COPCO MT5010	7-Mar-13	5-Apr-13	BD	W2003206	weld up exhaust purifier and replace tubing
TR13	ATLAS COPCO MT5010	8-Mar-13	8-Mar-13	BD	W2003259	replace afff pyro line
TR13	ATLAS COPCO MT5010	13-Mar-13	13-Mar-13	DA	W2003281	pos3 flat tyre
TR13	ATLAS COPCO MT5010	19-Mar-13	19-Mar-13	BD	W2003330	blown trans hose, c/o trans temp sender
TR13	ATLAS COPCO MT5010	27-Mar-13	27-Mar-13	PM	W2003389	MT5010 500HR SERVICE
TR13	ATLAS COPCO MT5010	5-Apr-13	30-Apr-13	PM	W2003445	Fit updated dipstick tube
TR13	ATLAS COPCO MT5010	5-Apr-13	5-Apr-13	PM	W2003463	MT5010 250HR SERVICE
TR13	ATLAS COPCO MT5010	1-May-13	1-May-13	PM	W2003652	MT5010 1,000HR SERVICE
TR13	ATLAS COPCO MT5010	4-Jun-13	5-Jun-13	PM	W2003836	MT5010 250HR SERVICE

TR13	ATLAS COPCO MT5010	1-Jul-13	30-Jun-14	PM	W2004358	TR13 - General Consumables FY 2013/2014
TR13	ATLAS COPCO MT5010	5-Jul-13	5-Jul-13	PM	W2004075	MT5010 500HR SERVICE
TR13	ATLAS COPCO MT5010	12-Jul-13	25-Jul-13	PM	W2004094	fit front driveline guard
TR13	ATLAS COPCO MT5010	24-Jul-13	25-Jul-13	PM	W2004248	MT5010 250HR SERVICE
TR13	ATLAS COPCO MT5010	14-Aug-13	14-Aug-13	BD	W2004445	start fault-pbrake switch sticking
TR13	ATLAS COPCO MT5010	4-Sep-13	4-Sep-13	PM	W2004629	c/o engine oil/filters for first 50hr run in
TR13	ATLAS COPCO MT5010	5-Sep-13	5-Sep-13	BD	W2004617	repair a/c
TR13	ATLAS COPCO MT5010	14-Sep-13	15-Sep-13	PM	W2004709	MT5010 1,000HR SERVICE
TR13	ATLAS COPCO MT5010	17-Sep-13	18-Sep-13	BD	W2004725	power fault
TR13	ATLAS COPCO MT5010	6-Oct-13	7-Oct-13	PM	W2004878	MT5010 500HR SERVICE
TR13	ATLAS COPCO MT5010	20-Oct-13	21-Oct-13	PM	W2004985	MT5010 250HR SERVICE
TR13	ATLAS COPCO MT5010	30-Oct-13	30-Oct-13	PM	W2005076	c/o lh lift cyl grease line
TR13	ATLAS COPCO MT5010	3-Nov-13	4-Nov-13	BD	W2005108	replace broken afff hoses
TR13	ATLAS COPCO MT5010	16-Nov-13	17-Nov-13	PM	W2005219	MT5010 1,000HR SERVICE
TR13	ATLAS COPCO MT5010	30-Nov-13	1-Dec-13	PM	W2005332	MT5010 250HR SERVICE
TR13	ATLAS COPCO MT5010	3-Dec-13	3-Dec-13	PM	W2005348	up box light on c/o filter
TR13	ATLAS COPCO MT5010	15-Jan-14	16-Jan-14	PM	W2005503	MT5010 500HR SERVICE
TR13	ATLAS COPCO MT5010	26-Jan-14	26-Jan-14	BD	W2005564	repair damaged hand rail-could not fault
TR13	ATLAS COPCO MT5010	26-Jan-14	26-Jan-14	PM	W2005568	repair trans jumping in/out of gears
TR13	ATLAS COPCO MT5010	30-Jan-14	1-Feb-14	PM	W2005604	fit new fire extinguisher bag
TR13	ATLAS COPCO MT5010	1-Feb-14	1-Feb-14	PM	W2005776	MT5010 1,000HR SERVICE
TR13	ATLAS COPCO MT5010	18-Feb-14	18-Feb-14	BD	W2005765	c/o retarder pedal
TR13	ATLAS COPCO MT5010	21-Feb-14	21-Mar-14	PM	W2005796	apply all anti slip to engine bay covers/steps
TR13	ATLAS COPCO MT5010	25-Feb-14	11-Mar-14	BD	W2005800	reseal and replace spools for retarder valve block
TR13	ATLAS COPCO MT5010	2-Mar-14	21-Mar-14	PM	W2006173	MT5010 500HR SERVICE
TR13	ATLAS COPCO MT5010	10-Mar-14	10-Mar-14	BD	W2005923	blown drop box hose
TR13	ATLAS COPCO MT5010	12-Mar-14	12-Mar-14	PM	W2005982	repair door, front grill, bonnet, hand rails, steps
TR13	ATLAS COPCO MT5010	25-Mar-14	25-Mar-14	BD	W2006224	blown o-ring to valve block, replace coolant hose
TR13	ATLAS COPCO MT5010	25-Mar-14	25-Mar-14	BD	W2006239	repair radiator grille
TR13	ATLAS COPCO MT5010	26-Mar-14	26-Mar-14	PM	W2006300	repair guards
TR13	ATLAS COPCO MT5010	29-Mar-14	28-Mar-14	BD	W2006278	replace condensor
TR13	ATLAS COPCO MT5010	7-Apr-14	7-Apr-14	BD	W2006493	Replace leaking coolant header tank
TR13	ATLAS COPCO MT5010	7-Apr-14	8-Apr-14	BD	W2006571	wiring fault to convertor lock up-constantly engaged
TR13	ATLAS COPCO MT5010	11-Apr-14	11-Apr-14	BD	W2006658	repair front cooler cover
TR13	ATLAS COPCO MT5010	20-Apr-14	20-Apr-14	PM	W2006880	repair oil leak from case drain
TR13	ATLAS COPCO MT5010	28-Apr-14	28-Apr-14	BD	W2007123	repair door latch
TR13	ATLAS COPCO MT5010	28-Apr-14	28-Apr-14	BD	W2007133	no front lights-circuit breaker tripped
TR13	ATLAS COPCO MT5010	4-May-14	4-May-14	PM	W2007301	fit front driveline cover and retorque bolts
TR13	ATLAS COPCO MT5010	5-May-14	8-May-14	BD	W2007053	replace driveshaft centre bearing at center hitch
TR13	ATLAS COPCO MT5010	8-May-14	9-May-14	PM	W2007398	MT5010 1,000HR SERVICE
TR13	ATLAS COPCO MT5010	10-May-14	10-May-14	PM	W2007421	retorque drivelines
TR13	ATLAS COPCO MT5010	19-May-14	19-May-14	DA	W2007613	operator got tub stuck in backs
TR13	ATLAS COPCO MT5010	21-May-14	22-May-14	BD	W2007657	repair broken cooler mounts
TR13	ATLAS COPCO MT5010	26-May-14	26-May-14	PM	W2007798	reseal upbox pressure sensor
TR13	ATLAS COPCO MT5010	28-May-14	28-May-14	BD	W2007827	repair drob box fan
TR13	ATLAS COPCO MT5010	17-Jun-14	17-Jun-14	BD	W2008254	fit park brake switch
TR13	ATLAS COPCO MT5010	18-Jun-14	18-Jun-14	PM	W2008144	repair air con
TR13	ATLAS COPCO MT5010	18-Jun-14	19-Jun-14	PM	W2008227	MT5010 250HR SERVICE
TR13	ATLAS COPCO MT5010	19-Jun-14	19-Jun-14	BD	W2008148	replace reverse camera
TR13	ATLAS COPCO MT5010	23-Jun-14	23-Jun-14	DA	W2008387	replace broken hyd filler cap
TR13	ATLAS COPCO MT5010	28-Jun-14	28-Jun-14	BD	W2008528	test for low power
TR13	ATLAS COPCO MT5010	9-Jul-14	18-Jul-14	DA	W2008514	replace door window
TR13	ATLAS COPCO MT5010	11-Jul-14	11-Jul-14	PM	W2008766	MT5010 500HR SERVICE
TR13	ATLAS COPCO MT5010	14-Jul-14	14-Jul-14	PM	W2008837	c/o seat belt
TR13	ATLAS COPCO MT5010	22-Jul-14	22-Jul-14	PM	W2008997	daily service
TR13	ATLAS COPCO MT5010	29-Jul-14	30-Jul-14	BD	W2009185	top up drop box oil and fit side window
TR13	ATLAS COPCO MT5010	30-Jul-14	30-Jul-14	BD	W2009195	fit window back in
TR13	ATLAS COPCO MT5010	30-Jul-14	31-Jul-14	PM	W2009234	MT5010 250HR SERVICE
TR13	ATLAS COPCO MT5010	8-Aug-14	9-Aug-14	BD	W2009638	trans temp fault
TR13	ATLAS COPCO MT5010	18-Aug-14	18-Aug-14	DA	W2009873	replace door window
TR13	ATLAS COPCO MT5010	24-Aug-14	24-Aug-14	PM	W2009999	MT5010 1,000HR SERVICE
TR13	ATLAS COPCO MT5010	25-Aug-14	26-Aug-14	BD	W2009951	repair upbox/dropbox temp wiring
TR13	ATLAS COPCO MT5010	27-Aug-14	28-Aug-14	DA	W2010016	repair hyd leak hit wall
TR13	ATLAS COPCO MT5010	28-Aug-14	28-Aug-14	BD	W2010068	repair trans temp gauge-c/o sender
TR13	ATLAS COPCO MT5010	28-Aug-14	28-Aug-14	PM	W2010074	daily service
TR13	ATLAS COPCO MT5010	1-Sep-14	1-Sep-14	BD	W2010156	repair drop box wiring fault
TR13	ATLAS COPCO MT5010	2-Sep-14	2-Sep-14	BD	W2010251	inspect vibration, check final drives, replace high speed
TR13	ATLAS COPCO MT5010	3-Sep-14	3-Sep-14	PM	W2010276	retorque speed shaft
TR13	ATLAS COPCO MT5010	15-Sep-14	15-Sep-14	BD	W2010614	repair air con
TR13	ATLAS COPCO MT5010	24-Sep-14	24-Sep-14	BD	W2010887	tripping circuit breaker #6-repair
TR13	ATLAS COPCO MT5010	29-Sep-14	29-Sep-14	BD	W2010992	upbox light on-checked over, clean coolers
TR13	ATLAS COPCO MT5010	1-Oct-14	1-Oct-14	BD	W2011085	replace fan belt

TR13	ATLAS COPCO MT5010	2-Oct-14	2-Oct-14	BD	W2011079	replace alternator belt
TR13	ATLAS COPCO MT5010	12-Oct-14	13-Oct-14	PM	W2011312	MT5010 250HR SERVICE
TR13	ATLAS COPCO MT5010	13-Oct-14	13-Oct-14	PM	W2011338	repair fire suppression cover
TR13	ATLAS COPCO MT5010	15-Oct-14	15-Oct-14	BD	W2011411	free up steering column and daily service
TR13	ATLAS COPCO MT5010	19-Oct-14	19-Oct-14	BD	W2011514	check upbox light coming on-cleaned pressure sender
TR13	ATLAS COPCO MT5010	20-Oct-14	20-Oct-14	BD	W2011427	repair drop box pressure fault
TR13	ATLAS COPCO MT5010	20-Oct-14	20-Oct-14	BD	W2011518	upbox light on again-change out sender
TR13	ATLAS COPCO MT5010	23-Oct-14	24-Oct-14	BD	W2011589	circuit breaker #5 popping-seat wiring, repaired
TR13	ATLAS COPCO MT5010	27-Oct-14	27-Oct-14	PM	W2011683	daily service
TR13	ATLAS COPCO MT5010	2-Nov-14	2-Nov-14	PM	W2011853	MT5010 250HR SERVICE
TR13	ATLAS COPCO MT5010	8-Nov-14	8-Nov-14	BD	W2012002	check cab vibration
TR13	ATLAS COPCO MT5010	9-Nov-14	9-Nov-14	BD	W2012026	brake light coming on-low hyd pressure
TR13	ATLAS COPCO MT5010	11-Nov-14	15-Nov-14	BD	W2012078	diagnois brake charge/hyd fault-suspension cyl bypassing
TR13	ATLAS COPCO MT5010	22-Nov-14	22-Nov-14	BD	W2012334	replace seat from TR08
TR13	ATLAS COPCO MT5010	23-Nov-14	23-Nov-14	BD	W2012351	repair door latch and make new upbox cover hinge
TR13	ATLAS COPCO MT5010	27-Nov-14	26-Nov-14	PM	W2012430	replace missing hydraulic fill cap
TR13	ATLAS COPCO MT5010	28-Nov-14	28-Nov-14	BD	W2012505	clean coolers
TR13	ATLAS COPCO MT5010	1-Dec-14	1-Dec-14	BD	W2012574	replace afff hoses
TR13	ATLAS COPCO MT5010	8-Dec-14	9-Dec-14	BD	W2012759	free up brake spool and daily
TR13-CHASSIS	TR13- TRUCK CHASSIS	25-Oct-12	30-Oct-12	DA	W2002325	Replace all tyres.
TR13-CHASSIS	TR13- TRUCK CHASSIS	19-Dec-12	19-Dec-12	BD	W2002671	replace uni's in high speed shaft
TR13-CHASSIS	TR13- TRUCK CHASSIS	21-Feb-13	14-Feb-13	BD	W2003049	replace front driveline guard
TR13-CHASSIS	TR13- TRUCK CHASSIS	4-Jun-13	4-Jun-13	PM	W2003830	replace pos1,2 tyres
TR13-CHASSIS	TR13- TRUCK CHASSIS	5-Jun-13	5-Jun-13	PM	W2003835	c/o pos3,4 tyres
TR13-CHASSIS	TR13- TRUCK CHASSIS	7-Jun-13	7-Jun-13	DA	W2003855	rock fell on wheel guard breaking afff fittings-repaired
TR13-CHASSIS	TR13- TRUCK CHASSIS	2-Aug-13	1-Feb-14	PM	W2004257	Tray Reline
TR13-CHASSIS	TR13- TRUCK CHASSIS	28-Aug-13	28-Aug-13	BD	W2004543	replace centre bearing
TR13-CHASSIS	TR13- TRUCK CHASSIS	10-Sep-13	17-Sep-13	DA	W2004616	replace door window
TR13-CHASSIS	TR13- TRUCK CHASSIS	10-Sep-13	10-Sep-13	DA	W2004656	exhaust crushed by rocks-weld on new elbow
TR13-CHASSIS	TR13- TRUCK CHASSIS	23-Oct-13	23-Oct-13	DA	W2005002	pos2 flat tyre-operator hit wall
TR13-CHASSIS	TR13- TRUCK CHASSIS	16-Jan-14	16-Jan-14	PM	W2005497	C/o pos 1 and 2 tyres
TR13-CHASSIS	TR13- TRUCK CHASSIS	11-Mar-14	11-Mar-14	DA	W2005926	c/o rear tyres
TR13-CHASSIS	TR13- TRUCK CHASSIS	12-Mar-14	12-Mar-14	PM	W2005976	repair bonnet
TR13-CHASSIS	TR13- TRUCK CHASSIS	20-Apr-14	20-Apr-14	PM	W2006882	retorque high speed shaft
TR13-CHASSIS	TR13- TRUCK CHASSIS	27-Apr-14	27-Apr-14	DA	W2007122	replace blown tyre o-ring
TR13-CHASSIS	TR13- TRUCK CHASSIS	29-Apr-14	29-Apr-14	DA	W2007164	fit front window
TR13-CHASSIS	TR13- TRUCK CHASSIS	2-Jul-14	3-Jul-14	DA	W2008607	hit wall smashing front window
TR13-CHASSIS	TR13- TRUCK CHASSIS	17-Jul-14	17-Jul-14	BD	W2008888	repair front grille
TR13-CHASSIS	TR13- TRUCK CHASSIS	6-Aug-14	8-Aug-14	DA	W2009241	replace all tyres
TR13-CHASSIS	TR13- TRUCK CHASSIS	17-Oct-14	17-Oct-14	DA	W2011453	inspect damage tp pos 1 wheel
TR13-CHASSIS	TR13- TRUCK CHASSIS	7-Jan-15	7-Jan-15	PM	W2013122	replace tyres-fit old ones on
TR13-DVSHFT	TR13- TRUCK DRIVE SHAFTS	27-Apr-14	27-Apr-14	PM	W2006956	c/o centre shaft driveline
TR13-DVSHFT	TR13- TRUCK DRIVE SHAFTS	8-May-14	8-May-14	BD	W2007077	c/o uni's on all drivelines
TR13-DVSHFT	TR13- TRUCK DRIVE SHAFTS	8-May-14	8-May-14	PM	W2007144	TRUCKS-MT5010-REPLACE NO1 DRIVESHAFT UNIVERSAL JOINTS
TR13-DVSHFT	TR13- TRUCK DRIVE SHAFTS	8-May-14	8-May-14	PM	W2007145	TRUCKS-MT5010-REPLACE NO2 DRIVESHAFT UNIVERSAL JOINTS
TR13-DVSHFT	TR13- TRUCK DRIVE SHAFTS	8-May-14	8-May-14	PM	W2007146	TRUCKS-MT5010-REPLACE NO3 DRIVESHAFT UNIVERSAL JOINT
TR13-DVSHFT	TR13- TRUCK DRIVE SHAFTS	8-May-14	8-May-14	PM	W2007147	TRUCKS-MT5010-REPLACE SPEED SHAFT UNIVERSAL JOINTS
TR13-ELEC	TR13- TRUCK ELECTRICAL	4-Aug-11	4-Aug-11	PM	W2000364	replace tran pressure switch
TR13-ELEC	TR13- TRUCK ELECTRICAL	10-Aug-11	17-Aug-11	PM	W2000367	REPLACE FILTER BLOCKED HARNESS
TR13-ELEC	TR13- TRUCK ELECTRICAL	25-Apr-12	27-Apr-12	PM	W2001164	fit push button horn to dash
TR13-ELEC	TR13- TRUCK ELECTRICAL	19-Sep-12	19-Sep-12	BD	W2002145	overhaul AC
TR13-ELEC	TR13- TRUCK ELECTRICAL	21-Jul-13	21-Jul-13	BD	W2004214	replace upbox sensor loom
TR13-ELEC	TR13- TRUCK ELECTRICAL	24-Jul-13	24-Sep-13	BD	W2004223	C/o faulty reference sensor-dropbox
TR13-ELEC	TR13- TRUCK ELECTRICAL	11-Sep-13	18-Sep-13	PM	W2004673	repair tacho light and p/brake button light,side light
TR13-ELEC	TR13- TRUCK ELECTRICAL	11-Sep-13	13-Sep-13	BD	W2004682	replace light switch
TR13-ELEC	TR13- TRUCK ELECTRICAL	29-Sep-13	29-Sep-13	BD	W2004813	repair wiring to rear J box
TR13-ELEC	TR13- TRUCK ELECTRICAL	16-Oct-13	16-Oct-13	BD	W2004952	repair wiring harness for upbox
TR13-ELEC	TR13- TRUCK ELECTRICAL	22-Oct-13	22-Oct-13	BD	W2004993	c/o alternator
TR13-ELEC	TR13- TRUCK ELECTRICAL	26-Jan-14	26-Jan-14	BD	W2005566	repair fuel guage and tacho
TR13-ELEC	TR13- TRUCK ELECTRICAL	30-Jan-14	1-Feb-14	PM	W2005602	replace fuel senderand test fuel guage
TR13-ELEC	TR13- TRUCK ELECTRICAL	9-Mar-14	12-Mar-14	BD	W2005881	Replace damaged coolant level sensor harness
TR13-ELEC	TR13- TRUCK ELECTRICAL	12-Mar-14	19-Mar-14	PM	W2005885	Repair tacho, check engine light,
TR13-ELEC	TR13- TRUCK ELECTRICAL	13-Mar-14	13-Mar-14	BD	W2005997	repairs to centre J-block harnesses
TR13-ELEC	TR13- TRUCK ELECTRICAL	17-Mar-14	19-Mar-14	PM	W2006000	C/o solid state tacho relay
TR13-ELEC	TR13- TRUCK ELECTRICAL	10-Apr-14	9-Apr-14	PM	W2006600	Replace old and perished transmission spider harness
TR13-ELEC	TR13- TRUCK ELECTRICAL	11-Apr-14	11-Apr-14	PM	W2006657	repair reverse alarm
TR13-ELEC	TR13- TRUCK ELECTRICAL	19-Apr-14	19-Apr-14	BD	W2006870	c/o startermotor and wiring
TR13-ELEC	TR13- TRUCK ELECTRICAL	23-Apr-14	23-Apr-14	BD	W2006933	repair wiring for front lights
TR13-ELEC	TR13- TRUCK ELECTRICAL	1-May-14	1-May-14	PM	W2007215	repair axle temp/pressure harness
TR13-ELEC	TR13- TRUCK ELECTRICAL	3-May-14	3-May-14	BD	W2007268	repair front lights
TR13-ELEC	TR13- TRUCK ELECTRICAL	7-May-14	7-May-14	BD	W2007359	c/o main relay
TR13-ELEC	TR13- TRUCK ELECTRICAL	12-May-14	13-May-14	BD	W2007456	gear fault-park brake stuck on u/s circuit breaker

TR13-ELEC	TR13-	TRUCK ELECTRICAL	14-May-14	14-May-14	BD	W2007391	replace J-block front harness
TR13-ELEC	TR13-	TRUCK ELECTRICAL	16-May-14	17-May-14	BD	W2007571	front lights tripping out-repair
TR13-ELEC	TR13-	TRUCK ELECTRICAL	18-May-14	18-May-14	PM	W2007553	Prepare spare PLC for backup
TR13-ELEC	TR13-	TRUCK ELECTRICAL	19-May-14	19-May-14	BD	W2007557	Change out failed CB4
TR13-ELEC	TR13-	TRUCK ELECTRICAL	2-Jun-14	2-Jun-14	BD	W2007948	park brake fault-plc tripped
TR13-ELEC	TR13-	TRUCK ELECTRICAL	9-Jun-14	9-Jun-14	BD	W2008044	diagnois a/c fault
TR13-ELEC	TR13-	TRUCK ELECTRICAL	10-Jun-14	11-Jun-14	BD	W2008083	high beam lights tripping circuit breaker
TR13-ELEC	TR13-	TRUCK ELECTRICAL	11-Jun-14	11-Jun-14	BD	W2008084	park brake fault-wiring
TR13-ELEC	TR13-	TRUCK ELECTRICAL	14-Jun-14	14-Jun-14	BD	W2008194	lights tripping out-repaired electrics
TR13-ELEC	TR13-	TRUCK ELECTRICAL	16-Jun-14	16-Jun-14	BD	W2008214	repair dash lights
TR13-ELEC	TR13-	TRUCK ELECTRICAL	17-Jun-14	17-Jun-14	BD	W2008243	repairs to a/c
TR13-ELEC	TR13-	TRUCK ELECTRICAL	8-Aug-14	8-Aug-14	BD	W2009616	replace upbox pressure switch
TR13-ELEC	TR13-	TRUCK ELECTRICAL	9-Aug-14	10-Aug-14	BD	W2009667	repair drop box pressure sensor wiring harness
TR13-ELEC	TR13-	TRUCK ELECTRICAL	25-Aug-14	25-Aug-14	BD	W2009927	C/o broken dropbox level switch
TR13-ELEC	TR13-	TRUCK ELECTRICAL	30-Aug-14	31-Aug-14	BD	W2010193	upbox temp sensor fault-c/o loom
TR13-ELEC	TR13-	TRUCK ELECTRICAL	1-Sep-14	1-Sep-14	BD	W2010224	repair coolant level sensor harness
TR13-ELEC	TR13-	TRUCK ELECTRICAL	2-Sep-14	2-Sep-14	BD	W2010252	upbox wiring fault, c/o J block, c/o incorrect wiring, c/o
TR13-ELEC	TR13-	TRUCK ELECTRICAL	3-Sep-14	3-Sep-14	BD	W2010295	repair side light
TR13-ELEC	TR13-	TRUCK ELECTRICAL	6-Oct-14	6-Oct-14	BD	W2011156	upbox light coming on-loose connection sensor
TR13-ELEC	TR13-	TRUCK ELECTRICAL	6-Oct-14	7-Oct-14	BD	W2011165	electrical fault-short in fuel cooler wiring
TR13-ELEC	TR13-	TRUCK ELECTRICAL	9-Oct-14	9-Oct-14	BD	W2011249	repair wiring for drop box sensor
TR13-ELEC	TR13-	TRUCK ELECTRICAL	10-Oct-14	10-Oct-14	BD	W2011256	drop box light on-found 2x loose plugs
TR13-ELEC	TR13-	TRUCK ELECTRICAL	15-Oct-14	15-Oct-14	BD	W2011419	replace rear cab light and repair wiring
TR13-ELEC	TR13-	TRUCK ELECTRICAL	22-Oct-14	22-Oct-14	BD	W2011576	c/o starter motor and main fuse
TR13-ELEC	TR13-	TRUCK ELECTRICAL	29-Oct-14	29-Oct-14	BD	W2011732	CB06 breaker tripping out
TR13-ELEC	TR13-	TRUCK ELECTRICAL	3-Nov-14	3-Nov-14	BD	W2011867	repair seat wiring
TR13-ELEC	TR13-	TRUCK ELECTRICAL	4-Nov-14	4-Nov-14	BD	W2011918	replace main battery fuse
TR13-ELEC	TR13-	TRUCK ELECTRICAL	6-Nov-14	6-Nov-14	BD	W2011954	repair wiring to front lights and horn
TR13-ELEC	TR13-	TRUCK ELECTRICAL	7-Nov-14	7-Nov-14	BD	W2011978	front light wiring
TR13-ELEC	TR13-	TRUCK ELECTRICAL	10-Nov-14	10-Nov-14	BD	W2012044	ckeeck gear selection fault
TR13-ELEC	TR13-	TRUCK ELECTRICAL	28-Nov-14	28-Nov-14	PM	W2012500	repair side light
TR13-ELEC	TR13-	TRUCK ELECTRICAL	3-Dec-14	3-Dec-14	BD	W2012617	repair tub up alarm
TR13-ENG	TR13-	TRUCK ENGINE	17-Aug-11	17-Aug-11	BD	W2000383	Replace coolant hose and run up
TR13-ENG	TR13-	TRUCK ENGINE	25-Aug-11	25-Aug-11	PM	W2000471	Repair coolant pipe leak
TR13-ENG	TR13-	TRUCK ENGINE	29-Aug-11	29-Aug-11	PM	W2000431	Replace lower coolant pipe.
TR13-ENG	TR13-	TRUCK ENGINE	7-Sep-11	7-Sep-11	PM	W2000473	replace eng dip stick
TR13-ENG	TR13-	TRUCK ENGINE	14-Sep-11	5-Jan-12	PM	W2000510	replace exhaust gaskets
TR13-ENG	TR13-	TRUCK ENGINE	16-Mar-12	16-Mar-12	DA	W2001009	Replace damaged Flywheel housing.
TR13-ENG	TR13-	TRUCK ENGINE	8-Mar-13	8-Mar-13	BD	W2003265	replace broken fan spring
TR13-ENG	TR13-	TRUCK ENGINE	6-May-13	6-Jun-13	PM	W2003672	C/o leaking side cover seals
TR13-ENG	TR13-	TRUCK ENGINE	21-May-13	21-May-13	BD	W2003764	c/o fan tensioner bearings
TR13-ENG	TR13-	TRUCK ENGINE	2-Aug-13	26-Aug-13	PM	W2004253	TRUCKS MT5010 ENGINE CHANGE OUT 16,000HR
TR13-ENG	TR13-	TRUCK ENGINE	15-Aug-13	15-Aug-13	BD	W2004454	replace broken fan tensioner spring
TR13-ENG	TR13-	TRUCK ENGINE	7-Sep-13	7-Sep-13	BD	W2004646	replace idler pulley(took off TR08 to get going)
TR13-ENG	TR13-	TRUCK ENGINE	19-Sep-13	19-Sep-13	BD	W2004737	cummins to diagnosis eng fault-warranty
TR13-ENG	TR13-	TRUCK ENGINE	24-Sep-13	24-Sep-13	BD	W2004749	replace idler pulley
TR13-ENG	TR13-	TRUCK ENGINE	3-Oct-13	3-Oct-13	BD	W2004899	c/o belts and coolant pipe
TR13-ENG	TR13-	TRUCK ENGINE	11-Oct-13	26-Jan-14	PM	W2004884	replace engine mounts
TR13-ENG	TR13-	TRUCK ENGINE	20-Nov-13	21-Nov-13	BD	W2005263	replace broken idler spring
TR13-ENG	TR13-	TRUCK ENGINE	28-Nov-13	28-Nov-13	PM	W2005306	replace idler bearings
TR13-ENG	TR13-	TRUCK ENGINE	11-Dec-13	11-Dec-13	BD	W2005384	Diagnose check engine light fault.
TR13-ENG	TR13-	TRUCK ENGINE	8-Jan-14	8-Jan-14	BD	W2005470	replace radiator hose
TR13-ENG	TR13-	TRUCK ENGINE	31-Jan-14	1-Feb-14	BD	W2005629	replace idler pulley
TR13-ENG	TR13-	TRUCK ENGINE	5-Apr-14	7-Apr-14	BD	W2006530	coolant header tank leaking
TR13-ENG	TR13-	TRUCK ENGINE	11-Apr-14	11-Apr-14	PM	W2006612	replace radiator mount
TR13-ENG	TR13-	TRUCK ENGINE	30-Apr-14	30-Apr-14	BD	W2007185	c/o coolant hose
TR13-ENG	TR13-	TRUCK ENGINE	2-May-14	2-May-14	BD	W2007245	repaired coolant leak
TR13-ENG	TR13-	TRUCK ENGINE	7-May-14	7-May-14	BD	W2007345	fan belts u/s
TR13-ENG	TR13-	TRUCK ENGINE	15-May-14	14-May-14	BD	W2007535	repair coolant leak and c/o compressor belt
TR13-ENG	TR13-	TRUCK ENGINE	14-Jun-14	14-Jun-14	PM	W2008187	pressure test cooling system
TR13-ENG	TR13-	TRUCK ENGINE	4-Jul-14	4-Jul-14	BD	W2008644	check eng light coming on-coolant level sensor
TR13-ENG	TR13-	TRUCK ENGINE	11-Jul-14	11-Jul-14	PM	W2008703	Replacing air filter housing
TR13-ENG	TR13-	TRUCK ENGINE	11-Jul-14	11-Jul-14	DA	W2008701	replace damaged air filter housing
TR13-ENG	TR13-	TRUCK ENGINE	22-Jul-14	22-Jul-14	BD	W2009001	tighten alternator bracket and belts
TR13-ENG	TR13-	TRUCK ENGINE	8-Aug-14	8-Aug-14	PM	W2009387	replace front engine mounts
TR13-ENG	TR13-	TRUCK ENGINE	22-Aug-14	22-Aug-14	BD	W2009967	repair coolant hose leak
TR13-ENG	TR13-	TRUCK ENGINE	22-Aug-14	22-Aug-14	BD	W2009975	blown top radiator hose
TR13-ENG	TR13-	TRUCK ENGINE	26-Aug-14	27-Aug-14	BD	W2010052	blown coolant hose
TR13-ENG	TR13-	TRUCK ENGINE	14-Sep-14	14-Sep-14	BD	W2010662	replace engine oil filter hose
TR13-ENG	TR13-	TRUCK ENGINE	19-Oct-14	19-Oct-14	BD	W2011489	replace broken coolant clamp and top up
TR13-ENG	TR13-	TRUCK ENGINE	19-Oct-14	19-Oct-14	BD	W2011500	repair coolant leak-coolant filter leaking
TR13-ENG	TR13-	TRUCK ENGINE	2-Dec-14	2-Dec-14	BD	W2012613	c/o u/s radiator hose

TR13-FAXLE	TR13 - TRUCK FRONT AXLE	30-Sep-11	30-Nov-11	PM	W2000517	TRUCKS MT5010 AXLE CHANGE OUT 10,000HRS
TR13-FAXLE	TR13 - TRUCK FRONT AXLE	12-Feb-13	14-Feb-13	BD	W2003022	front diff u/s
TR13-FAXLE	TR13 - TRUCK FRONT AXLE	1-May-14	3-May-14	PM	W2007016	TRUCKS MT5010 AXLE CHANGE OUT 10,000HRS
TR13-FAXLE	TR13 - TRUCK FRONT AXLE	9-May-14	9-May-14	PM	W2007045	c/o pos1 sungear
TR13-HYD	TR13- TRUCK HYDRAULICS	9-Aug-13	20-Mar-14	PM	W2004319	replace hyd filler neck
TR13-HYD	TR13- TRUCK HYDRAULICS	16-Sep-13	16-Sep-13	BD	W2004714	replace brake cooling hose
TR13-HYD	TR13- TRUCK HYDRAULICS	28-Oct-13	28-Oct-13	BD	W2005032	Replace main steer/hoist hyd pump
TR13-HYD	TR13- TRUCK HYDRAULICS	26-Jan-14	1-Mar-14	PM	W2005565	replace LH steering cylinder
TR13-HYD	TR13- TRUCK HYDRAULICS	14-Mar-14	14-Mar-14	BD	W2006014	blown hose from drop box
TR13-HYD	TR13- TRUCK HYDRAULICS	15-Mar-14	16-Mar-14	BD	W2006022	blown hose to strut
TR13-HYD	TR13- TRUCK HYDRAULICS	16-Jul-14	16-Jul-14	BD	W2008889	replace trans cooler fitting, charge pump fitting,
TR13-HYD	TR13- TRUCK HYDRAULICS	6-Aug-14	6-Aug-14	BD	W2009551	blown trans hose
TR13-HYD	TR13- TRUCK HYDRAULICS	1-Sep-14	1-Sep-14	BD	W2009928	replace hyd return filter housing-taken from scoopy
TR13-HYD	TR13- TRUCK HYDRAULICS	7-Sep-14	9-Sep-14	BD	W2010362	diagnosis and repair lift cyl fault
TR13-HYD	TR13- TRUCK HYDRAULICS	5-Oct-14	6-Oct-14	BD	W2011131	blown front diff cooling hose
TR13-HYD	TR13- TRUCK HYDRAULICS	24-Oct-14	24-Oct-14	BD	W2011621	blown hose to secondary park brake coil
TR13-HYD	TR13- TRUCK HYDRAULICS	26-Oct-14	26-Oct-14	BD	W2011670	blown hose under cab
TR13-HYD	TR13- TRUCK HYDRAULICS	16-Nov-14	16-Nov-14	BD	W2012186	replace brake charge pump
TR13-HYD	TR13- TRUCK HYDRAULICS	16-Nov-14	16-Nov-14	BD	W2012187	refit brake charge pump suction hose
TR13-HYD	TR13- TRUCK HYDRAULICS	26-Nov-14	26-Nov-14	BD	W2012457	blown steering o-ring
TR13-RAXLE	TR13 - TRUCK REAR AXLE	30-Sep-11	3-Oct-11	PM	W2000516	TRUCKS MT5010 AXLE CHANGE OUT 10,000HRS
TR13-RAXLE	TR13 - TRUCK REAR AXLE	1-Mar-13	1-Mar-13	BD	W2003172	inspect and replace sungears
TR13-RAXLE	TR13 - TRUCK REAR AXLE	12-Jun-13	24-Jun-13	BD	W2003886	investigate rear axle -locked up
TR13-RAXLE	TR13 - TRUCK REAR AXLE	28-Oct-13	29-Oct-13	PM	W2005031	Replace rear diff pinion seal
TR13-RAXLE	TR13 - TRUCK REAR AXLE	3-Apr-14	5-Apr-14	BD	W2006420	Repair failed sungears and planetaries
TR13-RAXLE	TR13 - TRUCK REAR AXLE	12-Jul-14	13-Jul-14	BD	W2008734	rebuild failed fos 4 final drive assy,
TR13-RAXLE	TR13 - TRUCK REAR AXLE	31-Jul-14	31-Jul-14	PM	W2009255	inspect final drives
TR13-RAXLE	TR13 - TRUCK REAR AXLE	8-Sep-14	13-Sep-14	PM	W2010445	TRUCKS MT5010 AXLE CHANGE OUT 10,000HRS
TR13-TRANS	TR13 - TRUCK TRANSMISSION	11-Jul-11	12-Jul-11	BD	W2000320	Repair gear fault
TR13-TRANS	TR13 - TRUCK TRANSMISSION	8-Mar-12	26-Nov-12	PM	W2000994	TRUCKS MT5010 TRANS CHNGEOUT 8000HRS
TR13-TRANS	TR13 - TRUCK TRANSMISSION	3-Apr-12	19-Apr-12	PM	W2001080	TRUCKS MT5010 TRANS CHNGEOUT 8000HRS
TR13-TRANS	TR13 - TRUCK TRANSMISSION	27-Apr-12	23-May-12	BD	W2001186	transmission1st/2nd gear failure.
TR13-TRANS	TR13 - TRUCK TRANSMISSION	31-May-12	4-Jun-12	PM	W2001495	40 hr tranny oil c/o
TR13-TRANS	TR13 - TRUCK TRANSMISSION	12-Jun-12	15-Jun-12	PM	W2001535	c/o leaking input shaft seal
TR13-TRANS	TR13 - TRUCK TRANSMISSION	28-Feb-13	28-Feb-13	BD	W2003151	trans light on -c/o filter
TR13-TRANS	TR13 - TRUCK TRANSMISSION	29-Mar-13	2-Apr-13	PM	W2003382	replace trans dipstick
TR13-TRANS	TR13 - TRUCK TRANSMISSION	13-May-13	15-May-13	BD	W2003691	Replace leaking retarder treadle valve
TR13-TRANS	TR13 - TRUCK TRANSMISSION	29-Jul-13	30-Jul-13	BD	W2004258	Replaced Top bearing in drop box
TR13-TRANS	TR13 - TRUCK TRANSMISSION	5-Aug-13	5-Aug-13	BD	W2004293	Replace dropbox cooler and fan
TR13-TRANS	TR13 - TRUCK TRANSMISSION	15-Aug-13	15-Aug-13	BD	W2004451	replace trans temp sender
TR13-TRANS	TR13 - TRUCK TRANSMISSION	31-Jul-14	31-Jul-14	BD	W2009155	replace leaking upbox-dropbox transfer pipe
TR13-U/BOX	TR13-UP DRIVE BOX	7-Mar-12	19-Mar-12	PM	W2000990	TRUCKS MT5010 UP BOX CHANGE OUT 5000HRS
TR13-U/BOX	TR13-UP DRIVE BOX	31-Aug-12	10-Sep-12	BD	W2002056	Dropbox c/o, heat damaged input shaft bearing
TR13-U/BOX	TR13-UP DRIVE BOX	3-Aug-13	3-Aug-13	BD	W2004290	replace dropbox speed sensor
TR13-U/BOX	TR13-UP DRIVE BOX	1-Sep-13	1-Sep-13	BD	W2004584	repair upbox leak-drain line
TR13-U/BOX	TR13-UP DRIVE BOX	29-Jan-14	30-Jan-14	BD	W2005611	replace drive line yoke
TR13-U/BOX	TR13-UP DRIVE BOX	24-Feb-14	24-Feb-14	BD	W2005808	C/o dropbox presure switch
TR13-U/BOX	TR13-UP DRIVE BOX	24-Feb-14	24-Feb-14	PM	W2005809	Replace up/box cooler
TR13-U/BOX	TR13-UP DRIVE BOX	21-Mar-14	22-Mar-14	BD	W2006165	remove up/box and repair leak